




Everdry4 man & lady size chart


unit: cm & kg

Everdry 4 man		S	M	MR	L	LR	XL	XLR	2XL	3XL
1	Suit length	119	125	127	132	133	138	139	144	150
2	Chest	98	101	104	104	107	107	110	110	113
3	Waist	84	87	91	91	94	94	98	98	101
4	Hips	98	100	102	102	104	104	106	106	108
	Torso length	73	77	77	80	80	84	84	87	91
5	Inseam	59	62	62	64	64	67	67	70	72
	Arm length	68	71	72	75	75	78	79	82	85
	Wrist cuff	14	14	15	15	16	16	17	17	17
	Ankle cuff	35	36	39	37	40	38	41	39	39
	Sock size	S	M	M	L	L	XL	XL	2XL	2XL
	Sole length for sock	25	26	26	28	28	28	28	28	28
	Hood size	S	M	M	L	L	XL	XL	XL	XL
	Head circumference	41	41	41	42	42	42	42	42	42
6	Height	170-175	175-180	175-180	180-185	180-185	185-190	180-190	190-195	195-200
	Weight (kg)	59-68	68-77	77-86	77-86	86-95	86-95	95-100	95-100	100-105



Tolerance is +/-2cm for measures 1 to 5

Everdry 4 lady		2XS	XS	S	M	L	XL
1	Suit length	120	124	128	133	138	143
2	Waist	73	75	77	79	81	84
3	Hips	96	100	104	107	110	113
	Torso length	75	77	79	81	83	85
4	Inseam	50	52	54	57	60	63
	Arm length	72	73	74	76	79	81
	Wrist cuff	14	14	14	15	16	17
	Ankle cuff	37	37	38	39	39	39
	Sock size	XS	XS	S	M	M	M
	Sole length for sock	24	24	25	26	26	26
	Hood size	XS	S	M	M	L	L
	Head circumference	38	39	39	39	41	41
5	Height	151-156	156-160	161-166	166-171	171-176	176-183
	Weight (kg)	40-45	45-50	50-55	55-62	62-75	75-84



Tolerance is +/-2cm for measures 1 to 4